

# Work Order ID 72302

**\*72302\***

Page 1

Monday, November 28, 2011 10:35:30 AM

Item ID: D350-766-011

Accept

**\*N900040100\***

Setup Start **\*NS1\***

Revision ID:

Item Name: Interior Trim, Aft Bulkhead

Stop **\*NS2\***

Start Date: 7/21/2011 Start Qty: 1.00

**\*1\***

Cust Item ID:

Required Date: 7/22/2011 Req'd Qty: 1.00

**\*1\***

Customer: CC-EAG001

Reference: RMA RA111245

Approvals: Process Plan: *mf*

Date: 11-11-28

Tooling:

Date:

Run Start **\*NR1\***

QC:

Date:

SPC (Y/N):

Date:

Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

IIN D350-766

Rev A

100

QC5- Inspect part completeness to step on W/O

0.00

**\*100\***

QC

Memo

0.00

Quality Control

INSPECT RA 111245  
D350-766-011 X 1 B56082

KIT USED FOR ENG TEST FIT

*8/17/14*

110

QC21- Final Inspection - Work Order Release

0.00

**\*110\***

QC

Memo

0.00

Quality Control

*To Be Scraped*

*11/12/14*

*11/12/14*